



## Polaris RZR XP 900/Trail 1000/Turbo (2 and 4) Rear Window Installation Instructions

### Parts Included (2 Seat):

(4) 1-3/4" Clamps

(8) 1" Bolts

(8) Neoprene Washers

(8) Nuts

### Parts Included (4 seat):

(6) 1-3/4" Clamps

(6) 1" Bolts

(6) Neoprene Washers

(6) Nuts

### Installation Instructions

1. Install the stainless-steel clamps with the straight, flat tab facing the rear of the RZR.  
*Note: Both clamp tabs will be inside the window, they will not sandwich the window.*
2. Line up the pre-drilled holes on the window with the clamps. Install a washer onto the supplied bolts, and then slide the bolts through the rear window and then through the clamps. Hand tighten with the supplied nuts.
3. For added security, line up the window with the mounts intended for the Polaris Click 6 Harnesses and insert the remaining bolts into the upper hole of the Click 6 harness mount. Hand tighten the bolts. (2 seat only)
4. Once the window is in place, tighten all nuts and bolts to a snug.

