



Pro XP Rear Windshield Installation

Parts Included:

- 1 each Bracket
- 2 each 1 3/4" Rubberized Stainless Steel Clamps
- 4 each 1" Stainless steel bolts
- 4 each 1/4" washers
- 4 each 1/4" nuts

Installation Instructions:

Step 1: Install bracket facing back using the 2 middle stock screws and leave loose enough to slide bracket if needed.



Step 2: Install Stainless Steel Clamps on the bar facing back. The windshield will attach to the bottom of the clamp below the cage cross bar. Note the clamp will be on one side of the windshield not sandwiched on both sides.

Step 3: From the trunk of Pro XP, position the back windshield using the bottom bracket as a guide. The windshield can be pushed into place and install screws in the top and bottom holes of the windshield. Once the windshield is in position tighten screws.

