

Door Insert Installation Instructions



Parts Included:

2 Polycarbonate Door Inserts
4 Push Pins (2 per door)

Tools Needed:

Drill and 5/16 bit

Open the door fully and loosen the 4 screws on the inside of the door panel – noted in blue. Loosen the bottom bracket noted in red.





Start from the front triangle and partially install between the frame and door- it will be a tight fit. Insert the top and bottom between the frame and door and the insert will snap into place.

Once the insert is in place, tighten the 4 screws and bottom bracket. Use the existing 2 holes in the Door Insert for pilot holes, drill through the door panel.

Close the door and insert the push pins from the outside – one on the top and one on the bottom, noted in red.

