

Can Am X3 4-Seater (2017+) Split Roof Installation Instructions



Top View
(Rear of Vehicle)

Parts Included:

- (1) Tinted Polycarbonate Roof with Wind Deflector
- (16) ¼" – 20 x 1" Black Oxide Bolts
- (20) Black Oxide Washers
- (16) ¼"-20 Nylon Hex Nuts
- (2) Fender Washers with Gaskets
- (6) 1-3/4" Clamps
- (6) Rubber Cushion Strips: 2- 66", 2- 60", 2- 48"
- (2) Triangle Front Support Braces

Installation Instructions:

1. Attach the 2 Triangle Front Support Braces onto the front of the roof with the supplied 1" screws, washers and lock nuts.
2. Unbolt the existing top support bars of the stock cage to allow the new H Bars to be put into their place. (You will need these new H Bars for the roof to work correctly).
3. Once new H Bars are in place, apply the 6 Rubber Cushion Strips in positions as indicated on the diagram.
4. Set the roof and clamps into place. Make sure that the roof is centered and aligned with the center bolt holes to align the 2-piece roof.
5. Tighten all the bolts to a snug and make sure to use the 2 Fender washers with the Fender Washer Gaskets on the rear two holes where it bolts directly into the cage.

