

## Can Am Maverick R 2024+ Full Windshield Installation



### Parts Included:

- (1)- Polycarbonate Windshield
- (2)- 36" Thin Rubber Seal

### ~ install with ~

- (2) 2" Stainless Steel Clamps
- (2) 1-3/4" Stainless Steel Clamps
- (6) 1-1/2" Black Bolts
- (6) 1/4" - 20 Stainless Steel Nuts
- (6) Black Washers
- (2) Fender Washers

### Tools needed for Installation:

- 7/16" Nut Driver
- 4.0mm Allen Wrench

1. Install the (2) 36" Thin Rubber Seal along the top of the bars of the roll cage.
2. Place the windshield in position in the front opening of the roll cage. Line up the very top holes to the factory holes on the roll cage. You will secure these with the fender washers going on the bottom side.
3. Install (2) 2" Stainless Steel clamps in the middle holes of the windshield. These clamps will go around the support brace in the roll cage. **(The 1-3/4" Clamps will not work for these holes. They will be used for the bottom two holes).**
4. Install (2) 1-3/4" Stainless Steel Clamps on the bottom two holes.
5. Once all bolts are started, you can then center the windshield and tighten all bolts to secure the windshield.

