

## Can Am Maverick R Rear Windshield Installation (2024+)



### Parts Included:

4- 3/4" Black Bolts	10- 1/4 Black Washers
4- M6 1-1/2" Bolts	6- 1/4 Lock Nuts
2- 1 1/2" Black Bolts	2- Rear Window Brackets
2- 1/2" Rubber Spacers	
2- Fender Washers	

### Installation Instructions:

1. Remove the (4) factory bolts located right behind the seat's headrest. There will be two on each side. Once these 4 bolts are removed, they will not be used again.
2. Align the (2) Rear Window Brackets in the slot where you took out the factory bolts behind the headrest. On the bracket, the hole that is facing closest to the roll cage will use a 1/2" Rubber Spacer on the back to ensure the bracket is straight to the Rear Windshield. You will use the 4 **M6 bolts** supplied to you to secure these brackets. (DO NOT TIGHTEN YET; ONLY START THE BOLTS)
3. From the backside of the machine, flex the windshield to get the window in. It will be tight. Some flexing is necessary to ensure a proper tight fit around the air scoop and roll bars.
4. Once brackets and window are in place, align the top of the rear window to the factory holes on the roll cage and secure it with the supplied hardware including the fender washers going from the underside.
5. Once all the bolts have been started, tighten each one to fully secure the rear window and enjoy!

